

特に注意していただきたいこと



夏の車の中など70度を越す恐れのある場所には絶対に放置しないでください。出来るだけ日陰や涼しい場所で保管してください。



一般電子機器の温度条件は以下の通りです。
保管温度：-20°C~70°C
動作温度：5°C~50°C



放り投げるなど絶対にしないでください。お取扱いにはご注意ください。故障や破損した状態で使用しないでください。



本製品の使用対象年齢は12歳以上を推奨しています。幼児や子供のみでは使用させないでください。



髪の毛を巻き込む恐れがありますので、脱着時には必ず電源を切ってから行ってください。



髪の毛の長い方は髪を束ねてご使用ください。



首部分を180度以上の回転はしないでください。



防水仕様ではありません。汗程度はOKです。

Important stuff you need to know about your WFan!

- 1) "Put it on, turn it on! Turn it off, take it off!" Always remember to turn-on your WFan after you have put it on, and turn-off before removing!
- 2) During the summer the internal temperature of a car can easily rise about 158F or 70C, so please do not leave or store WFan in hot car or similar temperature conditions
- 3) Be sure you store your WFan in a cool dry environment so it is ready to use when you need it! Ideal storage temperature 40F-100F.
- 4) Use your WFan in temperatures between 40F-122F.
- 5) Always handle product with care. We know you know this, but the WFan is not a toy, so please do not throw. Discontinue use immediately if broken.
- 6) Intended for use by individuals 12+.
- 7) For folks with beautiful long hair, please be sure to secure up and back with elastic hair band prior to use. If hair does get caught in fan, turn off immediately.
- 8) While the fan-head arms are flexible, please do not rotate/bend to either side beyond 180.
- 9) WFan is perfect for humid climates, but not in the rain as it is not waterproof. Wipe product dry if it gets wet.